



BEFORE SILENCING & RESETTING THE PANEL PLEASE ENSURE YOUR FIRE PROCEDURES HAVE BEEN FOLLOWED

FIRE ALARM CONTROL PANEL RESET INSTRUCTIONS

USE THE SCROLL $\uparrow\downarrow$ BUTTONS TO SEE FIRE EVENTS.

Silencing the alarm sounders

To silence any active alarm sounders, enter access level 2 (Turn the key) and momentarily press the SILENCE / RESOUND SOUNDERS button.
The alarm sounders will cease to sound and the panel's General Fire and relevant Fire Zone LEDs will go steady.

TO SILENCE THE SOUNDERS – TURN THE KEY AND THEN PRESS



Important, before resetting the panel you must investigate the cause of the alarm / fire and update the log book.

Our emergency call out number is 07792 468 899.

Resetting the panel

After the cause of an alarm has been cleared and the alarm sounders have been silenced, the panel can be reset by pressing the CONTROL PANEL RESET button.

The panel will give a double beep to indicate the reset process has started and, after a few seconds, the Fire Zone LEDs and General Fire LED will go out to indicate the process is complete. If there are still any fire conditions on any zones, the panel will go back into alarm as before.

TO RESET THE PANEL –

IF NEEDED TURN THE KEY (control buttons will time out after 5 minutes)

CONTROL PANEL RESET

◆ **Fire Alarm Installs** ◆ **Fire Alarm Service** ◆ **Emergency Lighting** ◆ **CCTV** ◆